Installing Driver under Windows ME/9x

(The device name shown in the installation should be WinFast TV 2000. And the steps below are under Windows XP.)

Installing the First Driver

Step 1:
Turn on your PC and start up your Windows.

Step 2:
Shortly after entering the Windows , you will see the **Found New Hardware Wizard** dialog box as shown in the first figure to the right. Tick the option for '**Install from a list or specific location**'. Then click **Next.**

Step 3:
The wizard will next prompt you to choose your search and installation options as shown in the second figure to the right. Tick '**Include this location in the search**' then give the location: **E:\WinFast TV\DRV** (assuming E is your CD-ROM drive location), or browse for it. And then click **Next**.

Step 4:
The wizard will then start searching for the driver at the given location.

Step 5:
A warning message about compatibility appears. Click **Continue Anyway.**

Step 6:
The windows will then start installing the first driver (WinFast TV 2000 WDM Video Capture). A dialog box with a progress bar appears.

1

Step 7:
When the installation of the first driver of WinFast TV 2000 is completed. A dialog box appears as shown in the figure to the right. Click **Finish.**

Installing the Second Driver

Step 8:
After finishing installing the first driver, the **Found New Hardware Wizard** dialog box restarts. Tick the option for '**Install from a list or specific location**'. Then click **Next**.

Step 9:
Like the first time, the wizard prompts you to choose your search and installation options. Tick '**Include this location in the search**' then give the location: **E:\WinFast TV\DRV** (assuming E is your CD-ROM drive location), or browse for it. And then click **Next**.


Step 10:
The wizard will then start searching for the driver at the given location.

Step 11:
A warning message about compatibility appears. Click **Continue Anyway.**

2

Step 12:
The windows will then start installing the second driver (WinFast TV 2000 WDM Audio Capture). A dialog box with a progress bar will then appears. When the installation is done. The wizard will display a dialog box to tell you so. Click **Finish**.

Installing the Third Driver

Step 13:
Again, the **Found New Hardware Wizard** dialog box restarts. Tick the option for '**Install from a list or specific location**'. Then click **Next.**

Step 14:
Like the last time, the wizard prompts you to choose your search and installation options. Tick '**Include this location in the search**' then give the location: **E:\WinFast TV\DRV** (assuming E is your CD-ROM drive location), or browse for it. And then click **Next**.

Step 15:
The wizard will then start searching for the driver at the given location.

Step 16:
A warning message about compatibility appears. Click **Continue Anyway.**

Step 17:
The windows will then start installing
the third driver (WinFast TV 2000
WDM TV Tuner). A dialog box with a
progress bar will then appears. When
the installation is done. The wizard will
display a dialog box to tell you so.
Click **Finish**.

Installing the Fourth Driver

Step 18:
Again, the **Found New Hardware
Wizard** dialog box restarts. Tick the
option for '**Install from a list or
specific location**'. Then click **Next**.

Step 19:
Like the last time, the wizard
prompts you to choose your
search and installation options.
Tick '**Include this location in
the search**' then give the
location: **E:\WinFast TV\DRV**
(assuming E is your CD-ROM
drive location), or browse for it.
And then click **Next**.

Step 20:
The wizard will then start searching for
the driver at the given location. Then a
warning message about the compatibility
appears. Click **Continue Anyway**.

Step 21:
The windows will then start
installing the fourth driver
(WinFast TV 2000 WDM
Crossbar). A dialog box with a
progress bar appears will then
appears. When the installation
is done. The wizard will
display a dialog box to tell
you so. Click **Finish**.